HONOR
earbuds

True Wireless Stereo Earbuds
Quick Start Guide

Contents

EN 1–8
ES 9–16
PT 17–24
FR 25–32
DE 33–40
IT 41–48

Read this guide before using the device, and make sure it doesn't damage other.

Safety information

- Do not use the device in areas, damp, or dirty environments or near magnetic fields, or in extreme temperatures.
- Adjust the volume to a safe level when you listen to music or make calls with the earbuds. Prolonged exposure to high volume levels may cause hearing damage.
- Do not use the earbuds while driving.
- Do not pierce, crush or drop the earbuds, or cause it with a sharp or other items. Do not use the device when it is in a damaged condition such as a flat or a cracked battery, or damaged charger, or damaged earbuds.
- Do not dismantle, modify, or attempt to repair the earbuds, or insert foreign objects into it, or immerse it in water or other liquids. Do not place the earbuds in ovens or hot ones.
- Do not let children or pets bite or suck the device. Power off the device when not in use.
- Do not use or store the device in areas with a temperature below -10°C and 45°C (14°F and 113°F). Extreme heat or cold may damage the device.
- Keep the earbuds away from pacemakers and other medical devices.
- Keep earbuds out of the reach of children.
- Do not use the earbuds in areas where the use of wireless devices is prohibited.
- Disassembly and modifications may result in the factory warranty being voided.
- If the device malfunctions, please contact our customer service center.
- Do not dispose of the device and its accessories in a manner that is harmful to the environment. Please follow local laws and regulations on the disposal of the device and its accessories, or return them to HONOR.
- Do not use the earbuds in areas with explosives. Otherwise, the earbuds may get damaged and cause an explosion or a fire.
- Do not use powerful chemicals, strong cleaning agents or detergents to clean the earbuds. Otherwise, the earbuds may get damaged. Wipe the earbuds with a soft cloth.

Packing list

Earbuds (Left and Right)	1 pair
Charging case	1
Type-C charging cable	1 (only Europe, Local)
Quick Guide	1
Warranty card	1

Basic specifications

Model: HONOR Earbuds Stereo Earbuds
Product number: CET-S
Charging case: CET-C
Max output: 100 mW
Operating frequency: 2.402–2.480 GHz
Operation temperature: -10 to 45 °C (14 to 113 °F)
Operation frequency: 2402–2480 MHz
Maximum radio power: 2.402–2.480 GHz: 11.00 dBm (EIRP)

Appearance

Power-off

Charging the charging case

Entering Pairing mode

Pairing

Factory reset

Music playback operations

Calling operations

Voice assistant activation

Indicators

Charging case	Blinking red	Low battery
	Steady red	Charging
	Steady blue	Fully charged
	Off	Not charging
Earbuds	Blinking red	Low battery
	Blinking blue	Pairing
	Blinking red and blue alternately	Self-test
	Blinking red and blue alternately	Restoring factory settings
	Blinking red and blue alternately	Upgrading
	Blinking red and blue alternately	Disconnecting from the current paired device
	Blinking red and blue alternately	Entering Pairing mode
	Blinking red and blue alternately	Entering Voice pickup mode
	Blinking red and blue alternately	Entering Voice assistant mode
	Blinking red and blue alternately	Entering Self-test mode
	Blinking red and blue alternately	Entering Restoring factory settings mode
	Blinking red and blue alternately	Entering Disconnecting from the current paired device mode
	Blinking red and blue alternately	Entering Pairing mode
	Blinking red and blue alternately	Entering Voice pickup mode
	Blinking red and blue alternately	Entering Voice assistant mode
	Blinking red and blue alternately	Entering Self-test mode
	Blinking red and blue alternately	Entering Restoring factory settings mode
	Blinking red and blue alternately	Entering Disconnecting from the current paired device mode

Maintenance

- Keep the device and its accessories dry. Do not dry the device with an external heat source such as a microwave oven or a hair dryer.
- Do not place the device and its accessories in areas with a temperature below -10°C and 45°C (14°F and 113°F). Extreme heat or cold may damage the device.
- Do not place the device and its accessories near equipment that is sensitive to electromagnetic radiation, or they may affect the operation of the equipment. Do not place the device in or its accessories near a heat, cold, and dry or dusty place, or they may be damaged.
- Do not place any magnetic objects near the earbuds, or it may affect connectivity. Take the device for a long time or drive may damage the cable.

Głośnik lewego

Głośnik prawego

Połączenie głosowe

Odłączanie słuchawek

Samodiagnoza

Przywracanie ustawień fabrycznych

Tryb wyłączenia

Tryb odbioru głosu słuchawek

Głośnik

Dotknij dwukrotnie, aby włączyć lub wyłączyć odtwarzanie.
Dotknij dwukrotnie, aby odebrać lub zakończyć połączenie.
Dotknij trzykrotnie, aby odrzucić przychodzące połączenie.
Dotknij dwukrotnie, aby aktywować asystenta głosowego.
Dotknij trzykrotnie, aby rozłączyć słuchawki z bieżącym sparowanym urządzeniem.
Dotknij dwukrotnie, aby uruchomić samodiagnozę słuchawek.
Dotknij trzykrotnie, aby przywrócić ustawienia fabryczne słuchawek.
Dotknij i przytrzymaj, aby przełączyć między redukcją szumów, przezroczystością i trybem wyłączenia.
Dotknij i przytrzymaj, aby dostosować głośność.
Dotknij i przytrzymaj, aby przełączyć między trybami odbioru głosu słuchawek